

User Manual

Revision 1.000
English

DALI / Ethernet - Converter

(Order Code: HD67839-B2-Y, HD67839-B2-N)

for Website information:

www.adfweb.com?Product=HD67839

for Price information:

www.adfweb.com?Price=HD67839-B2

Benefits and Main Features:

- ⊕ Very easy to configure
- ⊕ Electrical isolation
- ⊕ Temperature range: -40°C/85°C (-40°F/185°F)



For others DALI products, see also the following links:

Converter DALI to

www.adfweb.com?Product=HD67832
www.adfweb.com?Product=HD67833
www.adfweb.com?Product=HD67840
www.adfweb.com?Product=HD67844
www.adfweb.com?Product=HD67845
www.adfweb.com?Product=HD67848
www.adfweb.com?Product=HD67849
www.adfweb.com?Product=HD67850

(BACnet/IP Master)
(BACnet/IP Slave)
(EtherNet/IP)
(Modbus TCP Master)
(Modbus TCP Slave)
(PROFINET)
(SNMP Manager)
(SNMP Agent)

Do you have an your customer protocol?

www.adfweb.com?Product=HD67003

Do you need to choose a device? do you want help?

www.adfweb.com?Cmd=helpme



User Manual

INDEX:

| | Page |
|----------------------------------|------|
| INDEX | 2 |
| UPDATED DOCUMENTATION | 2 |
| REVISION LIST | 2 |
| WARNING | 2 |
| TRADEMARKS | 2 |
| SECURITY ALERT | 3 |
| EXAMPLE OF CONNECTION | 4 |
| CONNECTION SCHEME | 5 |
| CHARACTERISTICS | 6 |
| CONFIGURATION | 6 |
| POWER SUPPLY | 7 |
| FUNCTION MODES | 8 |
| LEDS | 9 |
| DALI | 10 |
| ETHERNET | 11 |
| USE OF COMPOSITOR SW67839 | 12 |
| NEW PROJECT / OPEN PROJECT | 13 |
| SOFTWARE OPTIONS | 14 |
| SET COMMUNICATION | 16 |
| DALI ACCESS | 17 |
| UPDATE DEVICE | 18 |
| USE OF DALI CONSOLE SOFTWARE | 20 |
| STRUCTURE OF THE SOFTWARE | 21 |
| SETUP | 22 |
| NETWORK SETTING | 23 |
| ETHERNET PROTOCOL | 28 |
| MECHANICAL DIMENSIONS | 40 |
| ORDERING INFORMATIONS | 41 |
| ACCESSORIES | 41 |
| DISCLAIMER | 42 |
| OTHER REGULATIONS AND STANDARDS | 44 |
| WARRANTIES AND TECHNICAL SUPPORT | 43 |
| RETURN POLICY | 43 |

UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- ✚ Updated
- ✚ Related to the product you own

To obtain the most recently updated document, note the “document code” that appears at the top right-hand corner of each page of this document.

With this “Document Code” go to web page www.adfweb.com/download/ and search for the corresponding code on the page. Click on the proper “Document Code” and download the updates.

REVISION LIST:

| Revision | Date | Author | Chapter | Description |
|----------|------------|--------|---------|---------------|
| 1.000 | 15/06/2016 | Ff | All | First Release |
| | | | | |
| | | | | |
| | | | | |

WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning.

ADFweb.com is not responsible for any error this manual may contain.

TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.

SECURITY ALERT:**GENERAL INFORMATION**

To ensure safe operation, the device must be operated according to the instructions in the manual. When using the device, legal and safety regulation are required for each individual application. The same applies also when using accessories.

INTENDED USE

Machines and systems must be designed so the faulty conditions do not lead to a dangerous situation for the operator (i.e. independent limit switches, mechanical interlocks, etc.).

QUALIFIED PERSONNEL

The device can be used only by qualified personnel, strictly in accordance with the specifications. Qualified personnel are persons who are familiar with the installation, assembly, commissioning and operation of this equipment and who have appropriate qualifications for their job.

RESIDUAL RISKS

The device is state-of-the-art and is safe. The instruments can represent a potential hazard if they are inappropriately installed and operated by untrained personnel. These instructions refer to residual risks with the following symbol:




This symbol indicates that non-observance of the safety instructions is a danger for people that could lead to serious injury or death and / or the possibility of damage.

CE CONFORMITY

The declaration is made by our company. You can send an email to support@adfweb.com or give us a call if you need it.

EXAMPLE OF CONNECTION:



CONNECTION SCHEME:




Figure 1: Connection scheme for HD67839-B2

CHARACTERISTICS:

The HD67839 is a DALI / Ethernet - Converter.

It has the following characteristics:

- Up to 64 devices on DALI bus;
- Configurator for DALI network/devices;
- Isolation between DALI – Ethernet, Power Supply - Ethernet. Additional isolation Power Supply – DALI for HD67839-B2-N version;
- Two-directional information between DALI bus and Ethernet bus;
- Mountable on 35mm Rail DIN;
- Wide power supply input range: 8...24V AC or 12...35V DC;
- Wide temperature range: -40°C / 85°C [-40°F / +185°F].

CONFIGURATION:

You need “DALI Console” software on your PC in order to perform the following:



- Configure the DALI network;
- Setup the DALI devices (groups, scenes, IDs, ...);
- Test DALI communication.

You need Compositor SW67839 software on your PC in order to perform the following:

- Define the parameter of Ethernet line;
- Define the parameter of DALI line;
- Update the device.


POWER SUPPLY:

The devices can be powered at 8...24V AC and 12...35V DC. For more details see the two tables below.


| VAC  | | VDC  | |
|---|------|---|------|
| Vmin | Vmax | Vmin | Vmax |
| 8V | 24V | 12V | 35V |

Consumption at 24V DC:

| Device | Consumption [W/VA] |
|------------|--------------------|
| HD67839-B2 | 3.5 |



Caution: Not reverse the polarity power



HD67839-B2


FUNCTION MODES:

The device has got two functions mode depending of the position of the 'Dip1 of Dip-Switch A':

- The first, with 'Dip1 of Dip-Switch A' at "OFF" position, is used for the normal working of the device.
- The second, with 'Dip1 of Dip-Switch A' at "ON" position, is used for upload the Project and/or Firmware.

For the operations to follow for the updating, see 'UPDATE DEVICE' section.


According to the functioning mode, the LEDs will have specifics functions, see 'LEDS' section.



LEDS:

The device has got five LEDs that are used to give information of the functioning status.
The various meanings of the LEDs are described in the table below.


| LED | Normal Mode | Boot Mode |
|------------------------------------|--|---|
| 1: Device State (green) | Blinks slowly ($\sim 1\text{Hz}$) | Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress |
| 2: Ethernet communication (yellow) | Blinks when Ethernet communication is running | Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress |
| 3: DALI communication (yellow) | Blinks when DALI communication is running | Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress |
| 4: DALI error (yellow) | Turns ON when the DALI device is not present | Blinks quickly: Boot state Blinks very slowly ($\sim 0.5\text{Hz}$): update in progress |
| 5: Ethernet Link (green) | ON: Ethernet cable connected OFF: Ethernet cable disconnected | ON: Ethernet cable connected OFF: Ethernet cable disconnected |



DALI:

DALI stands for “Digital Adressable Lighting Interface” and it is an interface protocol for digital communication between electronic lighting equipment (electronic ballasts, transformers, etc.).

With the right choice of individual DALI components an extremely wide range of requirements can be met, from operating the lighting system from a simple light switch to lighting management systems for entire office complexes with thousands of light sources. Using ADFweb.com’s DALI converters, any light source, including incandescent lamps, fluorescent lamps, high-intensity discharge lamps and even LEDs, can be controlled irrespective of whether they are installed in an office, a restaurant or a street light.




| Characteristics | Description |
|--------------------------------|----------------------------------|
| Medium | Shielded Twisted Pair |
| Topology | Linear, Star or mixed |
| Device power consumption | Max 250 mA |
| DALI voltage | 9.5 V – 22.5 V (typical 16 V) |
| Maximum cable length | 300 m (1.5 mm ² wire) |
| Maximum number of DALI devices | 64 |
| Baud rate | 1200 bps |
| Maximum number of DALI groups | 16 |
| Maximum number of DALI scenes | 16 |

ETHERNET:

The Ethernet port is used for the Ethernet communication, for programming DALI network and for programming the device.

The Ethernet connection must be made using Connector2 of HD67839-B2 with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to an Hub/Switch is recommended the use of a straight cable, to connect the device to a PC is recommended the use of a cross cable.



USE OF COMPOSITOR SW67839:

To configure the Converter, use the available software that runs with Windows called SW67839. It is downloadable on the site www.adfweb.com and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site)*. The software works with MSWindows (XP, Vista, Seven, 8, 10; 32/64bit).

When launching the SW67839, the window below appears (Fig. 2).

**Note:**

It is necessary to have installed .Net Framework 4.





Figure 2: Main window for SW67839


NEW CONFIGURATION / OPEN CONFIGURATION:

The “**New Configuration**” button creates the folder which contains the entire device’s configuration.




A device’s configuration can also be imported or exported:


- To clone the configurations of a Programmable “DALI / Ethernet - Converter” in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button “**Open Configuration**”.



SOFTWARE OPTIONS:


By pressing the “**Settings**” () button there is the possibility to change the language of the software and check the updatings for the compositor.

In the section “Language” it is possible to change the language of the software.



In the section “Connection Options”, it is possible to check if there are some updatings of the software compositor in ADFweb.com website.

Checking the option “**Check Software Update at Start of Program**”, the SW67839 check automatically if there are updatings when it is launched.



In the section "Software Settings", it is possible to enable/disable some keyboard's commands for an easier navigation inside the tables contained in the different sections of the software.

SET COMMUNICATION:

This section define the fundamental communication parameters of Ethernet bus.

By Pressing the "**Set Communication**" button from the main window for SW67839 (Fig. 2) the window "Set Communication" appears (Fig. 3).

The means of the fields for the "Ethernet" section are:

- In the field "**IP ADDRESS**" the IP address of the converter is defined;
- In the field "**SUBNET Mask**" the SubNet Mask is defined;
- In the field "**GATEWAY**" the default gateway of the Ethernet network is defined. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net.

The means of the fields for the "DALI" section are:

- In the field "**DALI Console Port**" the UDP port used for Ethernet communication is defined.

**Note:**


For Ethernet communication, UDP protocol is allowed.

Figure 3: "Set Communication" window

DALI ACCESS:

By pressing the “**DALI Access**” button from the main window for SW67839 (Fig. 2) the window “Select the DALI Device Present in the Network” appears (Fig. 4).

This section is used to define the DALI devices connected to the converter. It is enough to check/uncheck the connected/unconnected DALI devices.



DALI Access

SW67839

Select the DALI Device Present in the Network

| | | | |
|--|--|--|--|
| <input checked="" type="checkbox"/> DALI ID Device 0 | <input type="checkbox"/> DALI ID Device 16 | <input type="checkbox"/> DALI ID Device 32 | <input type="checkbox"/> DALI ID Device 48 |
| <input checked="" type="checkbox"/> DALI ID Device 1 | <input type="checkbox"/> DALI ID Device 17 | <input type="checkbox"/> DALI ID Device 33 | <input type="checkbox"/> DALI ID Device 49 |
| <input type="checkbox"/> DALI ID Device 2 | <input type="checkbox"/> DALI ID Device 18 | <input type="checkbox"/> DALI ID Device 34 | <input type="checkbox"/> DALI ID Device 50 |
| <input type="checkbox"/> DALI ID Device 3 | <input type="checkbox"/> DALI ID Device 19 | <input type="checkbox"/> DALI ID Device 35 | <input type="checkbox"/> DALI ID Device 51 |
| <input type="checkbox"/> DALI ID Device 4 | <input type="checkbox"/> DALI ID Device 20 | <input type="checkbox"/> DALI ID Device 36 | <input type="checkbox"/> DALI ID Device 52 |
| <input type="checkbox"/> DALI ID Device 5 | <input type="checkbox"/> DALI ID Device 21 | <input type="checkbox"/> DALI ID Device 37 | <input type="checkbox"/> DALI ID Device 53 |
| <input type="checkbox"/> DALI ID Device 6 | <input type="checkbox"/> DALI ID Device 22 | <input type="checkbox"/> DALI ID Device 38 | <input type="checkbox"/> DALI ID Device 54 |
| <input type="checkbox"/> DALI ID Device 7 | <input type="checkbox"/> DALI ID Device 23 | <input type="checkbox"/> DALI ID Device 39 | <input type="checkbox"/> DALI ID Device 55 |
| <input checked="" type="checkbox"/> DALI ID Device 8 | <input type="checkbox"/> DALI ID Device 24 | <input type="checkbox"/> DALI ID Device 40 | <input type="checkbox"/> DALI ID Device 56 |
| <input type="checkbox"/> DALI ID Device 9 | <input type="checkbox"/> DALI ID Device 25 | <input type="checkbox"/> DALI ID Device 41 | <input type="checkbox"/> DALI ID Device 57 |
| <input type="checkbox"/> DALI ID Device 10 | <input type="checkbox"/> DALI ID Device 26 | <input type="checkbox"/> DALI ID Device 42 | <input type="checkbox"/> DALI ID Device 58 |
| <input type="checkbox"/> DALI ID Device 11 | <input type="checkbox"/> DALI ID Device 27 | <input type="checkbox"/> DALI ID Device 43 | <input type="checkbox"/> DALI ID Device 59 |
| <input type="checkbox"/> DALI ID Device 12 | <input type="checkbox"/> DALI ID Device 28 | <input type="checkbox"/> DALI ID Device 44 | <input type="checkbox"/> DALI ID Device 60 |
| <input type="checkbox"/> DALI ID Device 13 | <input type="checkbox"/> DALI ID Device 29 | <input type="checkbox"/> DALI ID Device 45 | <input type="checkbox"/> DALI ID Device 61 |
| <input type="checkbox"/> DALI ID Device 14 | <input type="checkbox"/> DALI ID Device 30 | <input type="checkbox"/> DALI ID Device 46 | <input type="checkbox"/> DALI ID Device 62 |
| <input type="checkbox"/> DALI ID Device 15 | <input type="checkbox"/> DALI ID Device 31 | <input type="checkbox"/> DALI ID Device 47 | <input type="checkbox"/> DALI ID Device 63 |

OK Cancel Select All Clear All

Figure 4: “DALI Access” window

UPDATE DEVICE:

By pressing the **"Update Device"** button, it is possible to load the created Configuration into the device; and also the Firmware, if necessary.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' in ON position;
- Turn ON the device
- Connect the Ethernet cable;
- Insert the IP **"192.168.2.205"**;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" turn OFF the Device;
- Put Dip1 of 'Dip-Switch A' at OFF position;
- Turn ON the device.

If you know the actual IP address of the device, you have to use this procedure:

- Turn on the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

At this point the configuration/firmware on the device is correctly update.




Figure 5: "Update device" windows

**Note:**

When you install a new version of the software, if it is the first time it is better you do the update of the Firmware in the HD67839 device.

**Note:**

When you receive the device, for the first time, you also have to update the Firmware in the HD67839 device.

**Warning:**

If Fig. 6 appears when you try to do the Update try these points before seeking assistance:

- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- Check the LAN settings;
- Check the Wi-Fi settings;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- If you are using Windows Seven, Vista, 8 or 10 make sure that you have the administrator privileges;
- In case you have to program more than one device, using the "UDP Update", you have to cancel the ARP table every time you connect a new device on Ethernet. For do this you have to launch the "Command Prompt" and write the command "arp -d". Pay attention that with Windows Vista, Seven, 8, 10 you have to launch the "Command Prompt" with Administrator Rights;
- Pay attention at Firewall lock.




Figure 6: "Protection" window



In the case of HD67839 you have to use the software "SW67839": www.adfweb.com/download/filefold/SW67839.zip.

USE OF DALI CONSOLE SOFTWARE:

To configure DALI network and test the communication, it is possible to use the available software that runs with Windows called "DALI Console". It is downloadable on the site www.adfweb.com and its operation is described in this document. (*This manual is referenced to the last version of the software present on our web site*). The software works with MSWindows (XP, Vista, Seven, 8, 10; 32/64bit).

When launching the DALI Console, the window below appears (Fig. 7).





Figure 7: Main window for DALI Console

STRUCTURE OF THE SOFTWARE:

The software layout is very simple and it is structured in this way:

- **"Menu bar"** (Fig. 8, Point 1): it is possible to open the setup window and see the informations about the DALI Console software;
- **"Network view"** (Fig. 8, Point 2): it is possible to see all the DALI devices connected to the HD67839 converter, the groups and the scenes set;
- **"Settings / commands view"** (Fig. 8, Point 3): it is possible to set and manage the parameters to the single DALI device, to the groups or for the full network.



(1) Menu bar

(2) Network view

(3) Settings / commands view

Figure 8: Structure of DALI Console software

SETUP:

This section defines the connection's parameters to the Ethernet side of the HD67839 converter.


By Pressing the **"Setup"** button from the menu bar of the DALI Console software, the "SETUP" window appears (Fig. 9).




Figure 9: "Setup" window

The means of the fields for the "SETUP" window are:

- In the field **"DEVICE IP ADDRESS"** insert the IP address set inside the converter;
- In the field **"PRG PORT"** insert the communication port used for the Ethernet communication with the converter (the one programmed);
- By pressing **"SET ADDRESS ON DEVICE"** button, it is possible to program the ID of the DALI node connected to the converter.

 **IMPORTANT:** in order to set the ID of the DALI nodes, it is necessary to connect just one DALI node at time to the converter in order to avoid conflicts in the network.

NETWORK SETTING:

By pressing the  button in the Network view, it is possible to scan the full DALI network and find all the DALI devices, the groups set and the scenes configured.

By selecting the single DALI devices found, the single groups, the single scene or the entire DALI network, it is possible to manage and test the functioning of the network.

DEVICES:

The means of the fields for "DEVICE INFO" are:

- In the field "**Device Type**" the type of DALI device is printed;
- In the field "**Software version**" the software version of the DALI device is printed;
- In the fields "**Power Range**" the Min value, Actual Value and Max Value of the ADV of the DALI device is printed;
- In the fields "**DEVICE STATUS**" the actual status of the DALI device is printed.



Note:

This section is in Reading and it is used just to monitor the actual status of the selected DALI device.




Figure 10: "Device settings" window

The means of the fields for the "CONTROL COMMANDS" section are:

- In the "**POWER CONTROL**" bar it is possible to change the actual ADV of the selected DALI device;
- In the field "**COMMAND**" it is possible to select a DALI command to send to the selected DALI device. For set commands, it is possible to insert the value to set in the field "**xx**". As soon as the command to send is selected, the command is sent: in order to send the same command more times, it is possible to press the "**SEND COMMAND**" button;
- In the field "**COMMAND FEEDBACK**" the response from the DALI device is printed.



Note:

This section is used to test the functioning of the DALI device in the network and to set specific parameters if needed (like new Minimum or Maximum ADV value).

In the "GROUP MEMBERSHIP" section it is possible to see the Groups which the selected DALI device is in. The checked checkboxes mean that the device is in the correspondent groups, the unchecked checkboxes mean that the device is not included in the correspondent groups. It is possible to change the group settings for the selected DALI device by checking/unchecking the correspondent checkboxes.

In the "SET SCENES" section it is possible to see the programmed scenes of the selected DALI device, program new ones and activate them:

- By pressing the buttons "**GO TO: SCENE X**" it is possible to activate the correspondent scene inside the selected DALI device; the programmed ADV for the selected scene is defined in the drop-down list on the right;
- By selecting a value into the drop-down lists next to the "GO TO: SCENE x" buttons, it is possible to set the ADV associated to the correspondent scene. It is possible to select:
 - Value between 0 and 255: the scene will have the defined value of ADV;
 - ACT: the scene will take the programmed ADV value into the "POWER CONTROL" bar;
 - OFF: the scene is disabled.

GROUPS:

The means of the fields for the "CONTROL COMMANDS" section are:

- In the "**POWER CONTROL**" bar it is possible to change the actual ADV of the selected DALI group;
- In the field "**COMMAND**" it is possible to select a DALI command to send to the selected DALI group. For set commands, it is possible to insert the value to set in the field "**xx**". As soon as the command to send is selected, the command is sent: in order to send the same command more times, it is possible to press the "**SEND COMMAND**" button;
- In the field "**COMMAND FEEDBACK**" the response from the DALI group is printed.

**Note:**

This section is used to test the functioning of the DALI groups in the network.

In the "SET SCENES" section it is possible to activate the programmed scenes to the selected group:

- By pressing the buttons "**GO TO: SCENE X**" it is possible to activate the correspondent scene inside the selected DALI group.




Figure 11: "Groups settings" window

SCENES:

By selecting a DALI scene from the Network view, it is possible to see the devices that have programmed the selected scene.

It is also possible to activate it by pressing the **"ACTIVATE SCENE X"** button.




Figure 12: "Scenes settings" window

ALL DEVICES (BROADCAST):

The means of the fields for the "CONTROL COMMANDS" section are:

- In the "**POWER CONTROL**" bar it is possible to change the actual ADV of the entire DALI network;
- In the field "**COMMAND**" it is possible to select a DALI command to send to the entire DALI network. For set commands, it is possible to insert the value to set in the field "**xx**". As soon as the command to send is selected, the command is sent: in order to send the same command more times, it is possible to press the "**SEND COMMAND**" button;
- In the field "**COMMAND FEEDBACK**" the response from the DALI network is printed.



Note:

This section is used to test the functioning of the DALI network.

In the "SET SCENES" section it is possible to activate the programmed scenes into all the DALI devices that have them:

- By pressing the buttons "**GO TO: SCENE X**" it is possible to activate the correspondent scene in the DALI network. Only the devices that have it will accept the command.




Figure 13: "Broadcast settings" window

ETHERNET PROTOCOL

DALI NETWORK SCANNING

This command is used to get the informations from the DALI nodes configured in the network.



Note:

This command must be sent to the UDP port 10000.

REQUEST

| | Byte 0 | Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 | Byte9 |
|------|--------|--------|--------|--------|--------|--------|--------|--------|--------|-------|
| Hex | 0x44 | 0x41 | 0x4C | 0x49 | 0x5F | 0x49 | 0x4E | 0x46 | 0x4F | 0x3D |
| Text | D | A | L | I | _ | I | N | F | O | = |

RESPONSE

The converter sends back as response an array of data of 512 bytes. For each DALI node, 8 bytes are reserved. Here's the data mapping of the data array sent:

| Byte | Data |
|---------|---------------------------------|
| 0-7 | Informations about DALI node 0 |
| 8-15 | Informations about DALI node 1 |
| 16-23 | Informations about DALI node 2 |
| 24-31 | Informations about DALI node 3 |
| 32-39 | Informations about DALI node 4 |
| 40-47 | Informations about DALI node 5 |
| 48-55 | Informations about DALI node 6 |
| 56-63 | Informations about DALI node 7 |
| 64-71 | Informations about DALI node 8 |
| 72-79 | Informations about DALI node 9 |
| 80-87 | Informations about DALI node 10 |
| 88-95 | Informations about DALI node 11 |
| 96-103 | Informations about DALI node 12 |
| 104-111 | Informations about DALI node 13 |
| 112-119 | Informations about DALI node 14 |
| 120-127 | Informations about DALI node 15 |
| 128-135 | Informations about DALI node 16 |
| 136-143 | Informations about DALI node 17 |
| 144-151 | Informations about DALI node 18 |
| 152-159 | Informations about DALI node 19 |
| 160-167 | Informations about DALI node 20 |
| 168-175 | Informations about DALI node 21 |
| 176-183 | Informations about DALI node 22 |
| 184-191 | Informations about DALI node 23 |
| 192-199 | Informations about DALI node 24 |
| 200-207 | Informations about DALI node 25 |
| 208-215 | Informations about DALI node 26 |
| 216-223 | Informations about DALI node 27 |
| 224-231 | Informations about DALI node 28 |
| 232-239 | Informations about DALI node 29 |
| 240-247 | Informations about DALI node 30 |
| 248-255 | Informations about DALI node 31 |

| Byte | Data |
|---------|---------------------------------|
| 256-263 | Informations about DALI node 32 |
| 264-271 | Informations about DALI node 33 |
| 272-279 | Informations about DALI node 34 |
| 280-287 | Informations about DALI node 35 |
| 288-295 | Informations about DALI node 36 |
| 296-303 | Informations about DALI node 37 |
| 304-311 | Informations about DALI node 38 |
| 312-319 | Informations about DALI node 39 |
| 320-327 | Informations about DALI node 40 |
| 328-335 | Informations about DALI node 41 |
| 336-343 | Informations about DALI node 42 |
| 344-351 | Informations about DALI node 43 |
| 352-359 | Informations about DALI node 44 |
| 360-367 | Informations about DALI node 45 |
| 368-375 | Informations about DALI node 46 |
| 376-383 | Informations about DALI node 47 |
| 384-391 | Informations about DALI node 48 |
| 392-399 | Informations about DALI node 49 |
| 400-407 | Informations about DALI node 50 |
| 408-415 | Informations about DALI node 51 |
| 416-423 | Informations about DALI node 52 |
| 424-431 | Informations about DALI node 53 |
| 432-439 | Informations about DALI node 54 |
| 440-447 | Informations about DALI node 55 |
| 448-455 | Informations about DALI node 56 |
| 456-463 | Informations about DALI node 57 |
| 464-471 | Informations about DALI node 58 |
| 472-479 | Informations about DALI node 59 |
| 480-487 | Informations about DALI node 60 |
| 488-495 | Informations about DALI node 61 |
| 496-503 | Informations about DALI node 62 |
| 504-511 | Informations about DALI node 63 |

Data map for each DALI node

| Offset | Description |
|--------|--|
| 0 | Status of DALI node |
| 1 | ADV of DALI node |
| 2 | Response received after command from DALI node |
| 3 | <ul style="list-style-type: none"> ➤ Bit 0, 1, 2, 3 (least significant) = Type of DALI node ➤ Bit 4, 5, 6, 7 (most significant) = Version of DALI node |
| 4 | Min. settable value of DALI node |
| 5 | Max. settable value of DALI node |
| 6-7 | <p>Each bit has a different meaning. '0' means 'Group not configured', '1' means 'Group configured'.</p> <ul style="list-style-type: none"> ➤ Byte 6, Bit 0 (less significant) = Group 0 ➤ Byte 6, Bit 1 = Group 1 ➤ Byte 6, Bit 2 = Group 2 ➤ Byte 6, Bit 3 = Group 3 ➤ Byte 6, Bit 4 = Group 4 ➤ Byte 6, Bit 5 = Group 5 ➤ Byte 6, Bit 6 = Group 6 ➤ Byte 6, Bit 7 (most significant) = Group 7 ➤ Byte 7, Bit 0 (least significant) = Group 8 ➤ Byte 7, Bit 1 = Group 9 ➤ Byte 7, Bit 2 = Group 10 ➤ Byte 7, Bit 3 = Group 11 ➤ Byte 7, Bit 4 = Group 12 ➤ Byte 7, Bit 5 = Group 13 ➤ Byte 7, Bit 6 = Group 14 ➤ Byte 7, Bit 7 (most significant) = Group 15 |

DALI SCENE SCANNING

This command is used to get the scenes configured into the DALI nodes configured in the network.

**Note:**

This command must be sent to the UDP port 10000.

REQUEST

| | Byte 0 | Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 | Byte9 |
|------|--------|--------|--------|--------|--------|--------|--------|--------|--------|-------|
| Hex | 0x44 | 0x41 | 0x4C | 0x49 | 0x5F | 0x53 | 0x43 | 0x45 | 0x4E | 0x3D |
| Text | D | A | L | I | _ | S | C | E | N | = |

RESPONSE

The converter sends back as response an array of data of 1024 bytes. For each DALI node, 16 bytes are reserved, one for each possible scene configured. Here's the data mapping of the data array sent:

| Byte | Data |
|-----------|-----------------------------------|
| 0-15 | Scenes configured on DALI node 0 |
| 16-31 | Scenes configured on DALI node 1 |
| 32-47 | Scenes configured on DALI node 2 |
| . | . |
| . | . |
| . | . |
| 1008-1023 | Scenes configured on DALI node 63 |

The bytes reserved for the scenes can have these values:

- 0-254 = Value set for the selected scene
- 255 = Scene not configured

**Note:**

In each group of 16 bytes, the first one is for the Scene 0 and the last one is for Scene 15.

ADV SETTING

This command is used to set the ADV for a specific DALI node, for a Group or for the entire DALI network.

REQUEST

| Byte Number | Description |
|-------------|---|
| 1 | DALI ID + 1 (Hex) |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | DALI ID (Hex) |
| 10 | ADV to set (Hex) |
| 11 | 0x00 |

The DALI ID can have different value in relation to the ADV to manage:

- 0 to 63 (0x00 to 0x3F) to manage a single DALI node;
- 64 to 79 (0x40 to 0x4F) to manage the Groups;
- 80 (0x50) for broadcast.

SCENE SETTING

This command is used to activate a programmed scene in a single DALI node, in a group or for the entire DALI network.

REQUEST

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | DALI ID + 0x80 (Hex) |
| 10 | Scene Number + 0x10 (Hex) |
| 11 | 0x00 |

The DALI ID can have different value in relation to the ADV to manage:

- 0 to 63 (0x00 to 0x3F) to manage a single DALI node;
- 64 to 79 (0x40 to 0x4F) to manage the Groups;
- 127 (0x7F) for broadcast.

The Scene Number can have a value between 0 and 15.

GENERIC DALI COMMAND

This command is used to send a generic DALI command to a DALI node, to a group or to the entire network.

REQUEST

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | DALI ID + 0x80 (Hex) |
| 10 | DALI Command (from DALI specifications) |
| 11 | 0x00 |

The DALI ID can have different value in relation to the ADV to manage:

- 0 to 63 (0x00 to 0x3F) to manage a single DALI node;
- 64 to 79 (0x40 to 0x4F) to manage the Groups;
- 127 (0x7F) for broadcast.

RESPONSE

The converter can send back two type of messages:

- "ANSWER=VAL" where 'VAL' is the answer from the DALI device;
- "ANSWER NOT RECEIVED" if any answer is received from the DALI node.

SCENE PROGRAMMING

This commands are used to program the scenes inside the DALI nodes. It is necessary to send two consecutive commands for the programming.

REQUEST 1

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | 0xD1 |
| 10 | ADV (Hex) |
| 11 | 0x00 |

REQUEST 2

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | DALI ID + 0x80 (Hex) |
| 10 | Scene Number + 0x40 (Hex) |
| 11 | 0x00 |

The DALI ID can have different value in relation to the ADV to manage:

- 0 to 63 (0x00 to 0x3F) to manage a single DALI node;
- 64 to 79 (0x40 to 0x4F) to manage the Groups;
- 127 (0x7F) for broadcast.

The Scene Number can have a value between 0 and 15.

GROUP SETTING

This command is used to enable/disable the membership of the DALI nodes inside the group.

REQUEST

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | DALI ID + 0x80 (Hex) |
| 10 | Group Number + 0x60 (Hex) = Enabling or Group Number + 0x70 (Hex) = Disabling |
| 11 | 0x00 |

The DALI ID can be from 0 to 63 (0x00 to 0x3F). The Group Number can be from 0 to 15.

NODE ID SETTING

These commands are used to program the ID Address on the DALI nodes. It is necessary to send them consecutively.



IMPORTANT: it is possible to connect a single DALI node to the HD67839 to program correctly the ID Node.

REQUEST 1

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | 0xD1 |
| 10 | (DALI_ID_to_set << 1) + 1 (Hex) |
| 11 | 0x40 |


REQUEST 2

| Byte Number | Description |
|-------------|---|
| 1 | 0x00 |
| 2 | 0x10 |
| 3 | 0x00 |
| 4 | 0x00 |
| 5 | 0x00 |
| 6 | 0x02 |
| 7 | 0x04 |
| 8 | Counter (increased for every command) (Hex) |
| 9 | 0xFF |
| 10 | 0x80 |
| 11 | 0x00 |



IMPORTANT: for correct setting, it is necessary to send the "REQUEST 2" two times. This is a specification from DALI protocol.

MECHANICAL DIMENSIONS:



Housing: PVC
Weight: 200g
(Approx)

Figure 14: Mechanical dimensions scheme for HD67839-B2-x

ORDERING INFORMATION:

The ordering part number is formed by a valid combination of the following:

HD67839 - B 2 - x

DALI Bus power supply

Y: present (the converter feeds the DALI bus)

N: not present (the converter doesn't feed the DALI bus)

Connectors Type

2: Fixed 5mm Screw Terminal

Enclosure Type

B: 2M, 35mm DIN Rail mounting

Device Family

HD67839: DALI / Ethernet - Converter

Order Code: **HD67839-B2-Y** - DALI / Ethernet - Converter (DALI bus power supply present)

Order Code: **HD67839-B2-N** - DALI / Ethernet - Converter (DALI bus power supply not present)

ACCESSORIES:

Order Code: **AC34001** - 35mm Rail DIN - Power Supply 220/240V AC 50/60Hz - 12 V AC

Order Code: **AC34002** - 35mm Rail DIN - Power Supply 110V AC 50/60Hz - 12 V AC

DISCLAIMER:

All technical content within this document can be modified without notice. The content of the document is a under continual renewal. For losses due to fire, earthquake, third party access or other accidents, or intentional or accidental abuse, misuse, or use under abnormal conditions repairs are charged to the user. ADFweb.com S.r.l. will not be liable for accidental loss of use or inability to use this product, such as loss of business income. ADFweb.com S.r.l. shall not be liable for consequences of improper use.

OTHER REGULATIONS AND STANDARDS:**WEEE INFORMATION**

Disposal of old electrical and electronic equipment (as in the European Union and other European countries with separate collection systems).

— This symbol on the product or on its packaging indicates that this product may not be treated as household rubbish. Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. If the product is disposed correctly, you will help prevent potential negative environmental factors and impact of human health, which could otherwise be caused by inappropriate disposal. The recycling of materials will help to conserve natural resources. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE

The device respects the 2002/95/EC Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (commonly referred to as Restriction of Hazardous Substances Directive or RoHS).

CE MARKING

The product conforms with the essential requirements of the applicable EC directives.

WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at www.adfweb.com. Otherwise contact us at the address support@adfweb.com

RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- Obtain a Product Return Number (PRN) from our internet support at www.adfweb.com. Together with the request, you need to provide detailed information about the problem.
- Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.



ADFweb.com S.r.l.
Via Strada Nuova, 17
IT-31010 Marenò di Piave
TREVISO (Italy)
Phone +39.0438.30.91.31
Fax +39.0438.49.20.99
www.adfweb.com

