

CP202-2CI
CAN-Bus Device Server User Manual

Version 1.0.0, Feb 2016

Shenzhen 3onedata Technology Co., Ltd

www.3onedata.com

Statement

Copyright Notice

Information in this document is reserved by Shenzhen 3onedata Technology Co., Ltd. Reproduction and extract without permission is prohibited.

Trademarks Notice



3onedata[®] and **3One data** is registered trademarks of Shenzhen 3onedata Technology Co.,Ltd. All other trademarks or registered marks in this manual belong to their respective manufacturers.

Agreement

As the product version upgrades or other reasons, this document is subject to change without notice. Unless other agreement, this document only as a guide to use. All statement, information and suggestion in this document, without warranty of any kind, either expressed or implied.

Revision History

| Version No. | Date | Reason |
|-------------|---------|--------------------|
| V1.0.0 | 2016-02 | Creating Documents |
| | | |

Notes

In reading this manual, please pay attention to the following symbols,



: Information necessary to explain.



: Special attention.

Content

| | |
|--|----|
| Chapter 1 Summarize | 1 |
| 1.1 Introduction | 1 |
| 1.2 Product Features | 1 |
| 1.3 Specification | 2 |
| Chapter 2 Hardware Description | 4 |
| 2.1 Interface Description | 4 |
| 2.2 Interface Description | 5 |
| 2.2.1 Power Input | 5 |
| 2.2.2 Communication Interface | 5 |
| 2.3 LED Indicator | 7 |
| 2.4 Factory Default | 7 |
| 2.5 Device installation | 7 |
| Chapter 3 Appearance and Dimension..... | 9 |
| Chapter 4 Packing List..... | 10 |
| Chapter 5 Web Management function..... | 11 |
| 5.1 Preparing configuration | 11 |
| 5.2 System statues | 14 |
| 5.3 CAN Server | 15 |
| 5.3.1 CAN Setting | 15 |
| 5.3.2 CAN Information | 20 |
| 5.4 Basic Settings | 21 |
| 5.4.1 Network & Reboot | 21 |
| 5.4.2 Login settings | 22 |
| 5.4.3 System Identification | 23 |
| 5.4.4 System File Update..... | 24 |
| 5.4.5 System Logout..... | 25 |
| Chapter 6 CAN-Bus Data Format Conversion | 26 |
| Chapter 7 Repair and Service | 29 |
| 7.1 Internet Service..... | 29 |
| 7.2 Make a call to our technical office..... | 29 |
| 7.3 Repair or Replace | 29 |

Chapter 1 Summarize

1.1 Introduction

CP202-2CI is an industrial grade CAN-Bus server which supports two CAN-Bus ports and a Fast Ethernet port. The user can easily complete the interconnection of CAN-Bus network and Ethernet network, to further expand the scope of CAN-Bus network. The CAN-Bus port communication rate 5K~1000Kbps has three operating modes of the TCP Server, TCP Client and UDP, support the most three connection, support across gateway, router communication, is convenient for user to visit the IP address or domain name and other functions. The host through the network centralized management, simple and convenient. It can be widely used in PLC control and management, building automation, healthcare automation system, the measurement instrument and dynamic environment monitoring system.

1.2 Product Features

- Support IEEE802.3, IEEE802.3u
- Support TCP Server, TCP Client and UDP working mode
- Support ARP, ICMP, UDP, TCP, IP, HTTP, DHCP and DNS protocol
- Support 10Base-T/100Base-TX auto speed control, Half/full duplex and MDI/MDI-X auto detect
- Support 2 Port CAN-Bus
- Support CAN-Bus baud rate 5K~1000Kbps
- Support across gateway, router communication
- Support static and dynamic IP access
- Support the heartbeat time and disconnect timeout function
- Support the automatic recovery function in the network connection is disconnected
- Support CAN-Bus port segment frame setting, to meet user message demand segmentation
- Support power input 9V ~ 24VDC, connection reverse protection function
- Industrial grade design, -40-75°C work temperature
- IP30 protection grade, wall mounting

1.3 Specification

Ethernet Interface

Standard: 10/100Base-T(x)

Speed: 10/100M auto-sensing

Signal: Rx+, Rx-, Tx+, Tx-

Protocol: ARP, ICMP, UDP, TCP, IP, HTTP, DHCP, DNS

Working: Full-duplex and half duplex

Working mode: TCP Server, TCP Client, UDP

Memory: 16K

Interface protection: 2KV surge protection, 0.5KV isolation protection

Transmission: 100m

Connector: RJ45

CAN-BUS Interface

Standard: CAN2.0A, CAN2.0B

CAN-Bus port number: 2

CAN-Bus signal: CANL, CANH

Band rate: 5K~1Mbps

Working mode: 2 wires, half duplex

Transfer distance: 40m~10Km

Load capacity: support 110 concurrent

Interface protection: 2KV surge protection, 2KV isolation protection

Connector: 10 bits terminal block

Power supply

Input voltage: 9~24VDC

Type of input: 4 bits terminal block

No-load consumption: .1.5W@12VDC

Interface protection: 1KV surge protection, 0.5KV isolation protection

Power support reverse connection

Working environment

Working temperature: -40~75°C

Storage temperature: -40~85°C

Relative Humidity: 5%~95% (no condensation)

Mechanical Structure

Shell: IP30 protect grade, metal shell

Installation: Wall mounting

Weight: 253g

Size (W×H×D): 70.6mm×26mm×94mm

Industry Standard

EMI: FCC Part 15, CISPR (EN55022) class A

EMS: EN61000-4-2 (ESD), Level 3

EN61000-4-4 (EFT), Level 4

EN61000-4-5 (Surge), Level 2

Shock: IEC 60068-2-27

Free fall: IEC 60068-2-32

Vibration: IEC 60068-2-6


Certification

CE, FCC, RoHS, UL508 (Pending)


Warranty: 3 years

Chapter 2 Hardware Description

2.1 Interface Description




1. Power input terminal block
2. Restore default settings (DEF)
3. 10Base-T /100Base-TX Ethernet port
4. CAN-Bus port terminal block
5. Equipment information
6. Wall mount ears
7. Run LED
8. Power indicator
9. CAN-Bus Link/ACT LED
10. Ethernet port Link/ACT LED
11. Ethernet port speed LED



2.2 Interface Description

2.2.1 Power Input




CP202-2CI CAN-Bus server provide DC power input, voltage input is the two terminal form (VI+, VI-), plug type 2 core spacing of 5.08mm terminals, wherein the power input range of 9 ~ 24VDC. The power support is not polarity that the device can still work normally after the reverse.

2.2.2 Communication Interface

10/100BaseT(X) Ethernet port

The pinout of RJ45 port display as below, connect by UTP or STP. The connect distance is no more than 100m. 100Mbps is used 120Ω of UTP 5; 10Mbps is used 120Ω of UTP 3, 4, 5.




RJ 45 port support automatic MDI/MDI-X operation. Can connect the PC, Server, Converter and HUB .Pin 1,2,3,6 Corresponding connections in MDI. 1→3, 2→6, 3→1, 6→2 are used as cross wiring in the MDI-X port of Converter and HUB. 10Base-T/100Base-TX are used in MDI/MDI-X, the define of Pin in the table as below.


| NO. | MDI signal | MDI-X signal |
|------------|------------|--------------|
| 1 | TX+ | RX+ |
| 2 | TX- | RX- |
| 3 | RX+ | TX+ |
| 6 | RX- | TX- |
| 4, 5, 7, 8 | — | — |

Note: “TX±”Transmit Data±, “RX±”Receive Data±, “—”Not Use.

MDI (straight-through cable)




MDI-X (Cross over cable)




MDI/MDI-X auto connection makes switch easy to use for customers without considering the type of network cable.

CAN-Bus interface



| NO. | Name | Define |
|-----|-------|--|
| 1 | CAN2L | CAN2 port CANL Signal Line |
| 2 | CAN2H | CAN2 port CANH Signal Line |
| 3 | R2ES+ | CAN2 port External Terminal Resistor (+) |
| 4 | R2ES- | CAN2 port External Terminal Resistor (-) |
| 5 | SHELL | Shell Ground |
| 6 | SHELL | Shell Ground |
| 7 | R1ES- | CAN1 port External Terminal Resistor (-) |
| 8 | R1ES+ | CAN1 port External Terminal Resistor (+) |
| 9 | CAN1H | CAN1 port CANH Signal Line |
| 10 | CAN1L | CAN1 port CANL Signal Line |

While CP202-2CI device connects with the CAN-Bus network via twisted pair, CANL connects with CANL, CANH connects with CANH. According to the ISO11898 standard, to reduce signal reflections on the CAN bus and enhance the reliability of communication, terminal matching resistor is usually added to 2 endpoints of the bus. The size of terminal matching resistor is decided by the characteristic impedance of cable transmission, such as twisted pair's characteristic impedance is 120Ω, the 2 endpoints on the bus should be connected 120Ω terminating resistor. CP202-2CI can set external terminating resistor, when the device is connected with the CAN-Bus network via a twisted pair, only use resistor to short circuit between the twisted pair ports RES+ and RES- to achieve terminal resistor accession, as shown below.




When the CP202-2CI converter is used as the CAN-bus network terminal, the two pin is connected to a resistance of 120Ω, otherwise no need to install a 120Ω resistor.

2.3 LED Indicator

LED indicator light on the top panel of product, the function of each LED is described in the table as below.

| System statue LED | | |
|---------------------|----------|---|
| LED | Indicate | Description |
| PWR (Red) | ON | Power is connected/Function natural |
| | OFF | Power is disconnected or function nu-natural |
| LINK | ON | Ethernet port connect successfully |
| | Flashing | Ethernet port has data transmission |
| | OFF | Ethernet port connect unsuccessfully |
| RUN | Flashing | System Running steadily |
| | OFF | System Running un-steadily |
| SPEED | ON | 100Mbps connection |
| | OFF | 10Mbps connection / the effective connection is not established |
| CAN1 | ON | CAN1 port normal working condition |
| | Flashing | CAN1 port work appeared fault |
| | OFF | CAN1 port working state is abnormal |
| CAN2 | ON | CAN2 port normal working condition |
| | Flashing | CAN2 port work appeared fault |
| | OFF | CAN2 port working state is abnormal |

2.4 Factory Default



Reset: restore the factory settings button, press and hold the DEF button, disconnect the power supply and then give the device to power up, continue for about 5 seconds to restore the factory settings.

2.5 Device installation


Before installation, confirm that the work environment meet the installation require, including the power needs and abundant space. Whether it is close to the connection equipment and other equipments are prepared or not.

1. Avoid in the sunshine, keep away from the heat fountainhead or the area where in intense EMI.
2. Examine the cables and plugs that installation requirements.
3. Examine whether the cables be seemly or not (less than 100m) according to reasonable scheme.
4. Power: 9 ~ 24VDC
5. Environment: working temperature: -40~75°C

Storage Temperature: -40~85°C

Relative humidity 5% ~95%

6. Support wall mounted

**Wiring Requirements**

Cable laying need to meet the following requirements:

1. It is needed to check whether the type, quantity and specification of cable match the requirement before cable laying.
2. It is needed to check the cable is damaged or not, factory records and quality assurance booklet before cable laying.
3. The required cable specification, quantity, direction and laying position need to match construction requirements, and cable length depends on actual position.
4. All the cable cannot have break-down and terminal in the middle.
5. Cables should be straight in the hallways and turning.
6. Cable should be straight in the groove, and cannot beyond the groove in case of holding back the inlet and outlet holes. Cables should be banded and fixed when they are out of the groove.
7. User cable should be separated from the power lines. Cables, power lines and grounding lines cannot be overlapped and mixed when they are in the same groove road. When cable is too long, it cannot hold down other cable, but structure in the middle of alignment rack.
8. Pigtail cannot be tied and swerved as less as possible. Swerving radius cannot be too small (small swerving causes terrible loss of link). Its banding should be moderate, not too tight, and should be separated from other cables.
9. It should have corresponding simple signal at both sides of the cable for maintaining.


Chapter 3 Appearance and Dimension

Appearance:

CP202-2CI



Dimension (Unit: mm)



Chapter 4 Packing List

The first time use this product, please check the packaging is intact or not and the attachment is complete or not at first.

| Item | Quantity |
|--|-----------------|
| Industrial CAN-Bus Device Server (plus terminal block) | 1pcs |
| Documentation and software CD | 1pcs |
| User manual | 1pcs |
| Warranty card | 1pcs |
| Wall mounting ears | 2pcs |
| Terminal resistance 120Ω | 2pcs |

Chapter 5 Web Management function

CP202-2CI have WEB server inside, you can manage and maintenance CP202-2CI directly perceived through the senses.

5.1 Preparing configuration

1. Requirements of PC

- 1). Install operate system (Like as Windows XP/2000/Win7)
- 2). Install network card
- 3). Install Web browser (Microsoft IE6.0 or higher version)
- 4). Install and start TCP/IP protocol

2. Establish correct network configuration

CP202-2CI default IP address: 192.168.1.254, subnet mask: 255.255.255.0, if configure in local area, please make sure IP's address configuration in a same subnet network before access the configuration view. If configure remote, PC and CP202-CI must reach by cross-router.


How to modify the PC's IP address

When access CP202-2CI through WEB, If PC and CP202-2CI in the same local area network, the IP address must in a same network segment, otherwise, PC and CP202-2CI must cross-router. When modify PC's address, please make sure PC and CP202-2CI in a same local area network, please reference the operation step as follows:

Control panel->Network connection->Local area connection->Properties->Internet protocol (TCP/IP)

CP202-2CI default IP address is: 192.168.1.254, configure PC's IP address to:192.168.1.X (X is a number except 254), after modify the PC's IP address, then we can use the default IP address: 192.168.1.254, then we can access and configure CP202-2CI through WEB.

Specify Windows system operates as follows:






This configuration example did not use “Advanced” button. If use this advanced configuration function, can let a same network card have some false IP address, then we can access CP202-2CI and did not modify the original IP address, but windows cannot deal with correctly in IGMP and IEEE 802.1X. Unix system did not have this problem, please note it when you use advanced function.

How to access Web Server

Open the Browser, input CP202-2CI’s default IP address in URL, after hit “Enter”, you will see the figure 5.1.1 as follows, point put user input user name and password, default user name and password are “admin”, if input incorrect, Web server has 3 time to input, if all incorrect, Browser will show “Access denied”. User must refresh the page and input correct user name and password. Please change the user name and password when you log in at first time. Please contact our service center if you have any other problems.



(Figure 5.1.1)

The default user name and password is [admin], it is case sensitive. The default password has administrator permission.

Web overtime handle

If user did not operate WEB management for a long time, systems will logout (But all the configuration will be saved)

Function menu:

| Item | Tabs | Function description | |
|-------------------|-----------------------|--|--|
| System statuses | Device information | Display device name, description, MAC address, contact information, Hardware and Firmware Ver etc | |
| CAN Server | CAN setting | CAN NO. setting | CAN1 and CAN2 optional that CAN-Bus port 1 and CAN-Bus port 2. |
| | | CAN parameter configuration | Choice sessions, work mode, local port, baud rate, CAN mode, Packs Frames, Pack time space, AT, time out, target port and target address . |
| | CAN information | Display statistics and connection information that send by CAN-Bus port. | |
| Basic information | Network & Reboot | Configure device's IP address, network mask, gateway, DNS server address. Restart device remotely. | |
| | Login setting | Modify user name and password | |
| | System identification | Display and configure device model name, serial number, description and contact information | |
| | System files update | Upload and download configuration files, system upgrade and factory default | |
| | Logout | Log out and come back log in statue | |



If user did not operate WEB management for a long time, system wills logout (But all the configuration will be saved). After overtime, if users want to do any configuration, system will note and come back login dialog box, if users want to operate, need to re-login. The overtime time is 300 seconds.

5.2 System statues

Device information

Current Location>>Main Menu>>System Status>>Overview

| Device Information | | | |
|--------------------|--------------|-----------------------|-------------------------|
| Module : | 2CAN | Hardware Ver : | 1.0.0 |
| Name : | CanServer | Firmware Ver : | 1.0.0B build2015052910R |
| Description : | 1LAN | MAC Address : | 00-22-6F-EE-00-01 |
| Serial No. : | 201505290001 | Contact Information : | |

(Figure 5.2.1)

| Item | Meaning |
|---------------------|--|
| Module | Network identification |
| Name | Device name |
| Description | The description of device’s features, like as used key place. |
| Serial No. | Serial number |
| Contact information | The contact information of person when maintenance the device, it can be configured in system information. |
| MAC address | Hardware address, 48bits(6 bytes), 16 hexadecimal, it is unique |
| Hardware version | The current hardware version information, please note the limit of software version to hardware version |
| Firmware version | The current software’s version information, upgrade software version will have more function |

5.3 CAN Server

5.3.1 CAN Setting

CAN No. Setting

Current Location>>Main Menu>>CAN Server>>CAN Settings

CANNo Setting

CAN No :

(Figure 5.3.1.1)

Users can CAN1 port and CAN2 port, and then the selected port configuration parameters. As shown above.

CAN parameter configuration

CAN port configuration menu:

| CAN port configuration menu | Optional data | Description |
|-----------------------------|---------------------------------------|-------------------------------|
| Sessions | 0, 1, 2, 3 | Support 3 session |
| Work mode | TCP Server, TCP Client, UDP | TCP work mode |
| Local port | 1~65535 | |
| Baud rate (bps) | 2K-1000K (20pcs band rate optional) | Baud rate choice |
| CAN mode | Normal, Listen only, selftest | Supports 3 modes of operation |
| Packs Frames | 1~50 | Checkout choice |
| Packs Time space(ms) | 1~254 | |
| AT(10ms) | 100~65525 | |
| Connect Timeout(10ms) | 100~65525 | |
| Clear CANBuffer | Never, Clear when TCP connect | |
| TCP Turbo | Disable, enable | |
| Target Port (1, 2, 3) | 1~65535 | |
| Target Address (1, 2, 3) | IP, Domain | 192.168.0.254 |

| CAN Parameters Settings | | | |
|--------------------------------------|--|---------------------------------------|--|
| Sessions : | <input type="text" value="1"/> | Work Mode : | <input type="text" value="TCP Serv"/> |
| | | Local Port : | <input type="text" value="32000"/> |
| Baudrate : | <input type="text" value="1000K"/> bps | CAN Mode : | <input type="text" value="Normal"/> |
| Packs Frames : | <input type="text" value="1"/> | Packs Time space : | <input type="text" value="1"/> ms |
| AT : | <input type="text" value="0"/> 10ms | Connect Timeout : | <input type="text" value="0"/> 10ms |
| Clear CANBuffer : | <input type="text" value="Never"/> | TCP Turbo : | <input type="text" value="Disable"/> |
| Target Port 1 : | <input type="text" value="33000"/> | Target Address 1 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> |
| Target Port 2 : | <input type="text" value="33001"/> | Target Address 2 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> |
| Target Port 3 : | <input type="text" value="33002"/> | Target Address 3 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> |
| <input type="button" value="Apply"/> | | <input type="button" value="Cancel"/> | |

(Figure 5.3.1.2)

Sessions

Each CAN-Bus port of the CAN-Bus server can support 0~3 sessions. The session refers to the CAN-Bus server from the CAN-Bus port of the received data to the Ethernet through socket. The number of sessions more than one, said the CAN-Bus server from the CAN-Bus port data received by more than one socket to Ethernet. The user can accord the required connection session to select the number of sessions.

CAN Mode

CAN-Bus port support three work modes: Normal, Listen only, Selftest.

Normal mode: The CAN-Bus server Normal work.

Listen only mode: The CAN-Bus server CAN-Bus port can receive data sent by myself.

Selftest mode: The CAN-Bus server is in the listening state, unable to send data.

Packs Frames

CAN-Bus export data into the Ethernet data frame length in the set time range, if the CAN-Bus data is greater than or equal to the set value when the frame length CAN-Bus server for data conversion, can set the value of 1-50.

Packs Time space

When CAN-Bus sends a data frame less waiting time, waiting time exceeds the server will then CAN-Bus data conversion, can set the value of 1-254.

Clear CANBuffer

Never: Never clean up the CANBuffer data cache

Clear when TCP connect: Clean up the data in the CANBuffer when the TCP connection

TCP Turbo

After the opening of TCP Turbo is equivalent to the sub frame is set to 1,

Note: enabling TCP Turbo, packs frames and packs time space is set of parameters will fail, only after closing the TCP Turbo packs frames and packs time is set of parameters will be effective

Local port

The CAN-Bus server provides can be connected to other TCP/IP nodes TCP port, TCP port and the corresponding CAN-Bus server CAN-Bus port associated.

Note: the client port range 0~65535 ("0" system automatically assign the local port number is not 0 when using a fixed local port number)

Target Port

The port that device will be connected, default is 1~65535

Target Address

The IP address or domain name address that device will connect, both of them can correspond the host computer address on the Internet.

Note: The target address 3 can only use the IP address.

AT

CAN-Bus server send the AT package accord the setting time, if no response continue, will be cut off.

If set " 0 " , meaning this function closed, the range is 100-65525, default is 0 second.

Connect Timeout

Setting the vacancy time for connection cut off automatic, if there do not have data transfer, the connection will cut off. If set "0", means do not care how much time vacancy, CAN-Bus server do not cut off voluntary.

The range is 100-65525. Default is 0 second.

Work Mode**1) TCP Client**

As TCP Client side, CAN-Bus device server will connect forwardly to TCP/IP network equipment, such as PC.

It need to setup to tell CAN-Bus device server to connect which network address and TCP port number when conditions is matched. After creating socket, CAN-Bus device server will sent the data received from each CAN-Bus port through socket On the contrary, the data received from socket will be sent to the corresponding CAN-Bus port.

The figure below is the configuration interface of TCP Client Mode. Session 1 is setting to local address available for router. "192.168.0.254", the "Target Port" connected to CAN-Bus port is host computer 192.168.0.254" 33000 port, please pay attention to pure TCP Client, TCP Server, or UDP mode.

CAN Parameters Settings

| | | | | | |
|-------------------|--|--------------------|--|--------------|------------------------------------|
| Sessions : | <input type="text" value="3"/> | Work Mode : | <input type="text" value="TCP Clien"/> | Local Port : | <input type="text" value="32000"/> |
| Baudrate : | <input type="text" value="1000K"/> bps | CAN Mode : | <input type="text" value="Normal"/> | | |
| Packs Frames : | <input type="text" value="1"/> | Packs Time space : | <input type="text" value="1"/> ms | | |
| AT : | <input type="text" value="0"/> 10ms | Connect Timeout : | <input type="text" value="0"/> 10ms | | |
| Clear CANBuffer : | <input type="text" value="Never"/> | TCP Trubo : | <input type="text" value="Disable"/> | | |
| Target Port 1 : | <input type="text" value="33000"/> | Target Address 1 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |
| Target Port 2 : | <input type="text" value="33001"/> | Target Address 2 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |
| Target Port 3 : | <input type="text" value="33002"/> | Target Address 3 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |

(Figure 5.3.1.3)

2) TCP server

TCP Server, Passive connect, one pivotal parameter is [Local port], have relationship with other setting, need combine setting.

The model is a kind of common usage patterns, use CAN-Bus server IP address and local port number 32000, you can used to establish a socket connection with other software programs or devices, the CAN-Bus server do for the TCP server only needs to wait for a TCP client to establish a connection can be communication.

CAN Parameters Settings

| | | | | | |
|-------------------|--|--------------------|--|--------------|------------------------------------|
| Sessions : | <input type="text" value="3"/> | Work Mode : | <input type="text" value="TCP Serv"/> | Local Port : | <input type="text" value="32000"/> |
| Baudrate : | <input type="text" value="1000K"/> bps | CAN Mode : | <input type="text" value="Normal"/> | | |
| Packs Frames : | <input type="text" value="1"/> | Packs Time space : | <input type="text" value="1"/> ms | | |
| AT : | <input type="text" value="0"/> 10ms | Connect Timeout : | <input type="text" value="0"/> 10ms | | |
| Clear CANBuffer : | <input type="text" value="Never"/> | TCP Turbo : | <input type="text" value="Disable"/> | | |
| Target Port 1 : | <input type="text" value="33000"/> | Target Address 1 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |
| Target Port 2 : | <input type="text" value="33001"/> | Target Address 2 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |
| Target Port 3 : | <input type="text" value="33002"/> | Target Address 3 : | <input type="text" value="IP"/> <input type="text" value="192.168.0.254"/> -- <input type="text" value="192.168.0.254"/> | | |

(Figure 5.3.1.4)

3) UDP Mode

Under the UDP work mode. CAN-Bus device server is server and also client, the relevant setting is “Local port”, “Target address” and “Target port”. It can support point to point and multicast UDP, setting method is the same as TCP.

CAN Parameters Settings

Sessions : Work Mode : Local Port :

Baudrate : bps CAN Mode :

Packs Frames : Packs Time space : ms

AT : 10ms Connect Timeout : 10ms

Clear CANBuffer : TCP Turbo :

Target Port 1 : Target Address 1 : --

Target Port 2 : Target Address 2 : --

Target Port 3 : Target Address 3 : --

(Figure 5.3.1.5)

5.3.2 CAN Information

1. CANNO Setting

Including CAN1 and CAN2

Current Location>>Main Menu>>CAN Server>>CAN Information

CANNO Setting

CANNO :

(Figure 5.3.2.1)

2. Statistics information

Statistical CAN-Bus send error message, CAN bus error information, and channel to send error information.

Statistics Information

CAN Send Error : 0 Frames


CAN BUS Error : 0 Frames

| | | | |
|----------------------|---------------|---------------|---------------|
| Channel Send Error : | 0 Frames(CH1) | 0 Frames(CH2) | 0 Frames(CH3) |
|----------------------|---------------|---------------|---------------|

(Figure 5.3.2.2)

3. Link information

Connection state information statistics CAN-Bus channel (including working mode, local port, target address and target port)



(Figure 5.3.2.3)

5.4 Basic Settings

5.4.1 Network & Reboot

Network setting

Configure IP address support 2 mode, DHCP and static IP address, When open DHCP function, can get the IP address from Hyper Terminal.

IP Address

IP address is an address of 32 bits length which is assigned to the device on the internet. The IP address consists of two fields: the network number field (net-id) and the Host ID field (host-id). For can conveniently manage IP address, IP addresses are divided into five categories. As blow:

| Network type | Address range | Available IP network range |
|--------------|---------------------------|----------------------------|
| A | 0.0.0.0~126.255.255.255 | 1.0.0.0~126.0.0.0 |
| B | 128.0.0.0~191.255.255.255 | 128.0.0.0~191.254.0.0 |
| C | 192.0.0.0~223.255.255.255 | 192.0.0.0~223.255.254.0 |
| D | 224.0.0.0~239.255.255.255 | Non |
| E | 240.0.0.0~246.255.255.255 | Non |
| Others | 255.255.255.255 | 255.255.255.255 |

A, B, C class address is unicast address; D class address is multicast address; E class address is reserved to prepare for the future for special purposes.

IP address using dotted decimal. Each IP address is represented as four decimal integers separated by decimal points; each integer corresponds to a byte, such as, 10.110.50.101.

Subnet Mask

Mask is corresponding 32 bits number of IP address. Some are 1, the others are 0. These 1 and 0 can be combined arbitrary in principle, but the first continuous bits are 1 when designing subnet mask. IP address can be divided into 2 parts by subnet mask: subnet address and host address. 1 in IP address and subnet corresponds to subnet address, other bits are host address. A type of address corresponding mask is 255.0.0.0; mask of B type address is 255.255.0.0; mask of C type address is 255.255.255.0.

Default Gateway

Default gateway in the host PC is generally called default route. Default route refer to a kind of router that destination address of IP data packet will choose when it don't find other existing route. All data packets of destination address which don't exist in the list of router will choose default route.

DNS Address

DNS (Domain Name Server) is for us to analyze domain to IP address of the Internet. If our equipment needs to access a host, you need to use this server to resolve an IP address.

Current Location>>Main Menu>>Basic Settings>>Network & Reboot

(Figure 5.4.1.1)

Device Reboot

Click the "Reboot " button is confirmed, the device restarts, 20 seconds, and then click the menu bar returns to the Web network login interface, save the configuration before you restart, or reboot and configuration information not saved will be lost.

(Figure 5.4.1.2)

5.4.2 Login settings

Knock [Basic settings/Login settings] menu, the figure as follows are CAN-Bus server initial interface to modify user name and password. User can use this function to modify user name and password.

Old user name

Allow English character, digit and "-" "_" combine and no more than 16 bytes

Old password

Allow English character, digit combine and no more than 20 bytes

New user name

Allow English character, digit and “-” “_” combine and no more than 16 bytes

New password

Allow English character, digit combine and no more than 20 bytes

Confirm password

Input password once again.

Current Location>>Main Menu>>Basic Settings >>Login Settings

Settings

Old User Name :

Old Password :

New User Name :

New Password :

Confirm Password :

Apply Cancel

(Figure 5.4.2)

5.4.3 System Identification

The figure as follows is the CAN-Bus device server information interface, we can see module, name, description, serial No. and contact information. You can modify these items through this function, it will available after reboot.

Module

No more than 18 bytes, allow Chinese character. English character, digit and “-” “_” but do not allow space

Name

No more than 18 bytes, allow Chinese character. English character, digit and “-” “_” but do not allow space

Description

No more than 18 bytes, allow Chinese character. English character, digit and “-” “_” but do not allow space

Serial No.

No more than 30 bytes, allow Chinese character. English character, digit and “-” “_” but do not allow space

Contact information

No more than 18 bytes, allow Chinese character. English character, digit and “-”“_”“@”“!”“,”“.” but do not allow space

Current Location>>Main Menu>>Basic Settings>>System Identification

Settings

Module :

Name :

Description :

Serial No. :

Contact Information :

(Figure 5.4.3)

5.4.4 System File Update

Current Location>>Main Menu>>Basic Settings>>System File Update

Factory Default

Load Factory Default :

Update Configuration File from Local PC

Download Configuration :

Upload Configuration :

Upgrade Firmware from Local PC

Upgrade Firmware :

(Figure 5.4.4)

1. Default factory (Please be care of this operation)

Knock<OK> button, After default factory, IP address is 192.168.1.254 and all configurations are the same as default factory. Default configuration will be available after reboot automatic. After recover default configuration, user name and password will be: admin.

2. Download configuration files

Knock<Download>Button, after confirm, system will appear a dialog box and point out to save the configuration file in .cfg. It is convenience to recover the configuration in future.

3. Upload configuration files

Knock< Browse> button, choice the correct .cfg file and knock <upload>, after confirm, configuration information in .cfg file uploaded to device automatic and reboot automatic.

4. Upgrade firmware

Knock <Browse> button, choice the position of the upgrade file. Knock<Upgrade> button. Point out "Forbid power off when upgrade", confirm it and then write flash. Reboot automatic, after upgrade, will refresh page automatic.



1. After default factory, must change the device's IP address, otherwise, if other devices make factory default, will have IP address conflict.
2. Please do not upgrade random. If you want to upgrade, must check the file is correct or not, otherwise, it is easy to damage the software.
3. Upgrade file must be bin type, please do not do any operations when upgrade, it may take upgrade failure. In upgrading, please do not operate the device and forbid know device's WEB page. If upgrade interrupt, please reboot the device and try again.

5.4.5 System Logout

Knock<OK> button, Web will be back to login interface, do not change available configuration, and figure as 5.4.5.

Current Location>>Main Menu>>Basic Settings>>Logout

System Logout :

OK

(Figure 5.4.5)

Chapter 6 CAN-Bus Data Format Conversion


The default list already occupied port by TCP and UDP protocol.

| Protocol | Port number |
|---------------------|-------------|
| (Retain) | 0 |
| TCP | 1 |
| (Retain) | 2 |
| ECHO | 7 |
| (Retain) | 9、11、13 |
| Network status | 15 |
| FTP | 20、21 |
| FTP | 21 |
| TELNET | 23 |
| SMTP | 25 |
| Printer | 35 |
| time server | 37 |
| NS | 42 |
| (Retain) | 43 |
| Login Host Protocol | 49 |
| DNS | 53 |
| DHCP | 67、68 |
| TETP | 69 |
| Gopler | 70 |
| Finger | 79 |
| HTTP | 80 |
| TELNET | 107 |
| SUN | 111 |
| NNTP | 119 |
| NTP | 123 |
| SNMP | 161、162 |
| IPX | 213 |
| (Retain) | 160-223 |

CAN-Bus data format conversion

A TCP or UDP frame comprises a plurality of CAN-Bus frames


(Up to 50, at least 1 CAN-Bus frames)



1 CAN-Bus frame contains 13 bytes



 Frame information: length of 1 bytes, for some information that identifies the CAN-Bus frame, such as type, length etc.



FF: standard frame and extended frame identification, 1 extended frame, 0 standard frame.

RTR: remote frame and data frame identification, 1 remote frames, 0 data frames.

Retain: the retention value is 0, 1 is not writable.

D3~D0: identifies the CAN frame data length.

 Frame ID: length of 4 bytes, a standard frame is 11 bits, 29 bits is effectively extended frame.




As for the representation of the extended frame ID 0X12345678




As for the representation of the standard frame ID 0X000003ff

 Frame data: 8 bytes, the effective length of frame information is determined by the value of D3~D0.



As for the expression of 8 valid data bytes



As for the expression of 6 valid data bytes

The following is an extended data frame, ID 0X12345678, contains 8 bytes of data (11h, 22h, 33H, 44h, 55h, 66h, 77h, 88H) expression of the frame

| | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 88h | 12h | 34h | 56h | 78h | 11h | 22h | 33h | 44h | 55h | 66h | 77h | 88h |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|


The following example is a standard data frame, ID 0X3FF, contains 6 bytes of data (11h, 22h, 33H, 44h, 55h, 66h) expression of the frame

| | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 06h | 00h | 00h | 03h | FFh | 11h | 22h | 33h | 44h | 55h | 66h | 00h | 00h |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|

Users in the use of PC to send UDP frame, CAN-Bus frame number of each UDP frame contains less than 50!

UDP frame transmission speed is not recommended more than 400 frames per second. Convert the CAN-Bus frame of not more than 4000 frames per second.

Application examples



(Figure 6.1)

Chapter 7 Repair and Service

The company provides a three-year product warranty, from the date of shipment. According to the product specifications, during the warranty period, the company will be free to repair or replace the product if the product has any failure or operation fails. However, these commitments do not cover damage caused by improper use, accident, natural disaster, improper operation or incorrect installation.

To ensure that consumers benefit from our managed series switches, try to get help in the following ways:

Internet service.

Make a call to our technical office.

Return or replace product.

7.1 Internet Service

Please visit <http://www.3onedata.com>

7.2 Make a call to our technical office

You can call our technical support office, the company has professional technical engineers to answer your questions and help you resolve your problems at the first time. Free Service Hotline 400-600-4496

7.3 Repair or Replace

Please to confirm with our technical staff if your product need to repair, replace or return, and then contact our sales man to get a deal with the problem. The above should be in accordance with the company's handler to negotiate for treatment with our technical and salesman to complete the repair, replacement or return.