

User Manual

Revision 1.000
English

Ethernet/IP / DeviceNet Slave - Converter

(Order Code: HD67598-A1)

for Website information:

www.adfweb.com?Product=HD67598

for Price information:

www.adfweb.com?Price=HD67598-A1

Benefits and Main Features:

- ▶ Very easy to configure
- ▶ Electrical isolation
- ▶ Two Ethernet/IP ports

Other
Products



For others Ethernet/IP products see also the following link:

Converter Ethernet/IP to

www.adfweb.com?Product=HD67077
www.adfweb.com?Product=HD67595
www.adfweb.com?Product=HD67598
www.adfweb.com?Product=HD67599
www.adfweb.com?Product=HD67589
www.adfweb.com?Product=HD67590
www.adfweb.com?Product=HD67590
www.adfweb.com?Product=HD67591
www.adfweb.com?Product=HD67591
www.adfweb.com?Product=HD67592
www.adfweb.com?Product=HD67592

(M-Bus)
(CAN)
(DeviceNet Slave)
(J1939)
(NMEA2000)
(Serial RS232)
(Serial RS485)
(Modbus Master RS232)
(Modbus Master RS485)
(Modbus Slave RS232)
(Modbus Slave RS485)

Do you have an your customer protocol?

www.adfweb.com?Product=HD67003

Do you need to choose a device? do you want help?

www.adfweb.com?Cmd=helpme

INDEX:

	Page
UPDATED DOCUMENTATION	2
REVISION LIST	2
WARNING	2
TRADEMARKS	2
INDEX	2
EXAMPLE OF CONNECTION	3
CONNECTION SCHEME	4
CHARACTERISTICS	5
CONFIGURATION	5
POWER SUPPLY	6
FUNCTION MODES	7
LEDS	8
ETHERNET/IP	9
USB	9
CAN	10
USE OF COMPOSITOR SW67598	11
NEW PROJECT / OPEN PROJECT	11
SET COMMUNICATION	12
UPDATE DEVICE VIA UDP	13
UPDATE DEVICE VIA USB	15
MECHANICAL DIMENSIONS	17
ORDERING INFORMATIONS	18
ACCESSORIES	18
WARRANTIES AND TECHNICAL SUPPORT	19
RETURN POLICY	19
PRODUCTS AND RELATED DOCUMENTS	19

UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- Updated
- Related to the product you own

To obtain the most recently updated document, note the "document code" that appears at the top right-hand corner of each page of this document.

With this "Document Code" go to web page www.adfweb.com/download/ and search for the corresponding code on the page. Click on the proper "Document Code" and download the updates.

To obtain the updated documentation for the product that you own, note the "Document Code" (Abbreviated written "Doc. Code" on the label on the product) and download the updated from our web site www.adfweb.com/download/

REVISION LIST:

Revision	Date	Author	Chapter	Description
1.000	21/06/2012	FI	All	First release version


WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning. ADFweb.com is not responsible for any error this manual may contain.

TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.

EXAMPLE OF CONNECTION:



CONNECTION SCHEME:




Figure 1: Connection scheme for HD67598-A1

CHARACTERISTICS:

The HD67598-A1 is a Ethernet/IP / DeviceNet Master Converter.

It allows the following characteristics:

- Up to 455 bytes in reading and 455 bytes in writing;
- Two-directional information between DeviceNet bus and Ethernet/IP bus;
- Mountable on 35mm Rail DIN;
- Power Supply 8...24V AC or 8...35V DC;
- Temperature range -40°C to 85°C.

CONFIGURATION:

You need Compositor SW67598 software on your PC in order to perform the following:

- Define the parameter of Ethernet/IP line;
- Define the parameter of DeviceNet line;
- Update the device.

POWER SUPPLY:

The devices can be powered at 8...24V AC and 12...35V DC. For more details see the two tables below.

VAC 		VDC 	
Vmin	Vmax	Vmin	Vmax
8V	24V	12V	35V


Consumption at 24V DC:

Device	Consumption [W/VA]
HD67598-A1	3.5

Connector1:
 Power Supply port
 0V = Ground
 +V = Positive wire
 V AC: min 8V ; max 24V
 V DC: min 12V ; max 35V



Caution: Not reverse the polarity power



HD67598-A1

FUNCTION MODES:

The device has got two functions mode depending of the position of the 'Dip2 of Dip-Switch B':

- The first, with 'Dip2 of Dip-Switch B' at "OFF" position, is used for the normal working of the device.
- The second, with 'Dip2 of Dip-Switch B' at "ON" position, is used for upload the Project and/or Firmware.

For the operations to follow for the updating, see 'UPDATE DEVICE' section.

According to the functioning mode, the LEDs will have specifics functions, see 'LEDS' section.




Warning:

Dip1 of 'Dip-Switch B' must be at ON position for working even if the Ethernet cable isn't inserted.

LEDS:


The device has got four LEDs that are used to give information of the functioning status.
The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode
1: Device State (green)	Blinks slowly (~1Hz)	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
2: DeviceNet State (green)	ON: Data exchange with a Master OFF: No data exchange with a Master	Blinks quickly: Boot state Blinks very slowly (~0.5Hz): update in progress
3: Ethernet1 Link (green)	ON: Ethernet cable connected OFF: Ethernet cable disconnected	ON: Ethernet cable connected OFF: Ethernet cable disconnected
4: Ethernet2 Link (green)	ON: Ethernet cable connected OFF: Ethernet cable disconnected	ON: Ethernet cable connected OFF: Ethernet cable disconnected



ETHERNET/IP:

The Ethernet/IP connection must be made using Connector3 and/or Connector4 of HD67595-A1 with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to an Hub/Switch is recommended the use of a straight cable, to connect the device to a PC/PLC/other is recommended the use of a cross cable.


**USB:**

The USB connection, must be made with a USB cable with a USB Mini B plug.
The USB port is used for programming the device.



DEVICENET:

For terminate the CAN line with a 120Ω resistor it is necessary that the Dip1 of 'Dip-Switch A' is at ON position.



Cable characteristics:

DC parameter:	Impedance	70 Ohm/m
AC parameters:	Impedance	120 Ohm/m
	Delay	5 ns/m
Length	Baud Rate [bps]	Length MAX [m]
	125 K	500
	250 K	250
	500 K	100

USE OF COMPOSITOR SW67598:

To configure the Converter, use the available software that runs with Windows, called SW67598. It is downloadable on the site www.adfweb.com and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site).* The software works with MSWindows (MS 2000, XP, Vista, Seven, 8; 32/64bit).

When launching the SW67595 the right window appears (Fig. 2).




Figure 2: Main window for SW67598

NEW PROJECT / OPEN PROJECT:

The **"New Project"** button creates the folder which contains the entire device configuration.



A device configuration can also be imported or exported:

- To clone the configurations of a Programmable "Ethernet/IP / DeviceNet Slave – Converter" in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button **"Open Project"**.

SET COMMUNICATION:

This section define the fundamental communication parameters of two buses, Ethernet/IP and DeviceNet.

By Pressing the "**Set Communication**" button from the main window for SW67598 (Fig. 2) the window "Set Communication" appears (Fig. 3).

The window is divided in two sections, one for the Ethernet/IP and the other for the DeviceNet.

The means of the fields for "Ethernet/IP" are:

- In the fields "**IP**" insert the IP address that you want to give to the Converter;
- In the fields "**SubNet Mask**" insert the SubNet Mask;
- In the fields "**Default Gateway**" insert the default gateway that you want to use. This feature can be enabled or disabled pressing the Check Box field;
- In the field "**Port**" insert the number of port;
- In the field "**Number Byte IN**" the number of byte from the Ethernet/IP to the Converter is defined (at maximum it is possible to use 455 byte);
- In the field "**Number Byte OUT**" the number of byte from the Converter to the Ethernet/IP is defined (at maximum it is possible to use 455 byte).

The means of the fields for the "DeviceNet" section are:

- In the field "**ID Dev.**" the address for the DeviceNet Master is defined;
- In the field "**Baud Rate**" the velocity of the DeviceNet bus is defined.

The screenshot shows a dialog box titled "SET COMMUNICATION". It is divided into two main sections: "Ethernet/IP" and "DeviceNet".

Ethernet/IP section:

- IP Address:** Four input fields containing "192", "168", "0", and "10".
- Subnet Mask:** Four input fields containing "255", "255", "255", and "0".
- Gateway:** A checked checkbox followed by four input fields containing "192", "168", "0", and "1".
- Port:** A single input field containing "44818".

DeviceNet section:

- ID Dev.:** A single input field containing "10".
- Baud rate:** A dropdown menu showing "500K".

At the bottom of the dialog are two buttons: "OK" with a green checkmark and "Cancel" with a red X.

Figure 3: "Set Communication" window

UPDATE DEVICE VIA UDP:

By pressing the **"Update Device via UDP"** button it is possible to load the created Configuration into the device; and also the Firmware, if is necessary.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn off the Device;
- Put Dip2 of 'Dip-Switch B' at ON position;
- Turn on the device
- Connect the Ethernet cable;
- Insert the IP **"192.168.2.205"**;
- Press the **"Ping"** button, must appear "Device Found!";
- Press the **"Next"** button;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" turn off the Device;
- Put Dip2 of 'Dip-Switch B' at OFF position;
- Turn on the device.

At this point the configuration/firmware on the device is correctly updated.




Figure 4: "Update device" windows

If you know the actual IP address of the device you have to use this procedure:

- Turn on the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Press the "**Ping**" button, must appear "Device Found!";
- Press the "**Next**" button;
- Select which operations you want to do;
- Press the "**Execute update firmware**" button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

At this point the configuration/firmware on the device is correctly update.



Note:

When you install a new version of the software it is better if the first time you do the update of the Firmware in the HD67598-A1 device.



Note:

When you receive the device, for the first time, you have to update also the Firmware in the HD67598-A1 device.



Warning:

If the Fig. 5 appears when you try to do the Update before require assistance try these points:

- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- If you are using Windows Seven or Vista or 8, make sure that you have the administrator privileges;
- Take attention at Firewall lock;
- Check the LAN settings.



In the case of HD67598-A1 you have to use the software "SW67598": www.adfweb.com/download/filefold/SW67598.zip.



Figure 5: "Protection" window

UPDATE DEVICE VIA USB:

By pressing the **Update Device via USB** button it is possible to load the created Configuration into the device; and also the Firmware, if is necessary.

In order to load the parameters or update the firmware in the device, follow these instructions:

- Turn off the Device;
- Connect the USB cable form your PC to the Converter;
- Put Dip2 of Dip-Switch B at "ON" position (see "FUNCTION MODES" section);
- Select the **COM port** and press the **Connect** button;
- Turn on the device;
- Check the Led. They must blink quickly (see "LEDS" section);
- Press the **Next** button;
- Select which operations you want to do.
- Press the **Execute update firmware** button to start the upload;
- When all the operations are "OK" turn off the device;
- Put Dip2 of Dip-Switch B at "OFF" position or disconnect the Boot jumper;
- Disconnect the USB Cable;
- Turn on the device.

At this point the configuration/firmware on the device is correctly update.




Figure 6: "Update Device" windows

**Note:**

When you install a new version of the software it is better if the first time you do the update of the Firmware in the HD67598-A1 device.

**Note:**

When you receive the device, for the first time, you have to update also the Firmware in the HD67598-A1 device.

**Warning:**

If the Fig. 7 appears when you try to do the Update before require assistance try these points:

- Check if the serial COM port selected is the correct one;
- Check if the USB or serial cable is connected between the PC and the device;
- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- If you are using Windows Seven or Vista or 8, make sure that you have the administrator privileges;
- Take attention at Firewall lock.




Figure 7: "Protection" window



In the case of HD67598-A1 you have to use the software "SW67598": www.adfweb.com/download/filefold/SW67598.zip.

MECHANICAL DIMENSIONS:




Housing: PVC
Weight: 200g (Approx)

Figure 8: Mechanical dimensions scheme for HD67598-A1

ORDERING INFORMATIONS:

The ordering part number is formed by a valid combination of the following:

HD67598 - A 1



Order Code: **HD670598-A1** - Converter Ethernet/IP / DeviceNet Slave Converter

ACCESSORIES:

Order Code: **AC34001** - 35mm Rail DIN - Power Supply 220/240V AC 50/60Hz - 12 V AC

Order Code: **AC34002** - 35mm Rail DIN - Power Supply 110V AC 50/60Hz - 12 V AC

WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at www.adfweb.com. Otherwise contact us at the address support@adfweb.com

RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- 1) Obtain a Product Return Number (PRN) from our internet support at www.adfweb.com. Together with the request, you need to provide detailed information about the problem.
- 2) Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.

PRODUCTS AND RELATED DOCUMENTS:

Part	Description	URL
HD67120	Converter Ethernet to RS232/RS485	www.adfweb.com?product=HD67120
HD67119	Converter USB 2.0 to RS485 Isolated	www.adfweb.com?product=HD67119
HD67507	Gateway Modbus TCP Server to RTU Master	www.adfweb.com?product=HD67507
HD67510	Gateway Modbus TCP Client to RTU Slave	www.adfweb.com?product=HD67510